For Internal Distribution Only

Accelerator Division
Alternating Gradient Synchrotron Department
BROOKHAVEN NATIONAL LABORATORY
Upton, New York 11973

Accelerator Division
Technical Note

AGS/AD/Tech. Note No. 443

BNL MAD Program Notes:
Survey Matching

J. Niederer

September 3, 1996

BNL MAD Program Notes:

Survey Matching

J. Niederer

AGS Department
Brookhaven National Laboratory

1. Summary

The set of position and direction calculations produced by the MAD Survey command has been added to the BNL MAD parameter matching ensemble. These simple procedures should help with designs of beam lines such as those between machines, where both lattice geometry and beam optics criteria may be involved. In a typical application, magnet positions and bend angles needed to guide beams into a fixed space point at a given angle might be computed. For example, in a possible rebuild of the BTA, major steering early in the line is modified in various ways to reduce dispersion. Bend angles and spacing among the bend magnets needs to be arranged so the beam is properly directed into the AGS entrance section, perhaps by satisfying a particular set of coordinates at the end of DH5.

Changes in the input language for the BNL Fast Match section are described. Where there is overlap with somewhat distantly related CERN v.8 features, similar command and attribute names have been used. An example bend angle tuning run is given for a BTA trial lattice with four early bends and 19 quads. All program changes are in the MatchF.B source file.

2. New FSurfit Command

The six spatial and direction angle coordinates of the start of a periodic beam line are entered with the **FSurfit** command. The angle definitions quoted are copied from the regular MAD User's Reference Manual. This command is not needed if all starting values are zero. Coordinate defaults are set to 0.m, direction defaults to 0. rad. In future applications, features may be added to use information on an existing reference Survey file for constraint or other values.

Svx	The starting X coordinate in meters, in the appropriate survey (global) system. Axes are the same as for the lattice optics, with the starting Z nominally in the direction of the beam.
Svy, Svz	The starting Y and Z survey coordinates in meters.
Svtheta	Azimuth angle in radians, between the global X and Z axes, about the global Y axis.

Svpsi	Tilt (roll) angle in radians about the local s axis. "The angle between the intersection of the local (x, y) and global (Z, X) planes and the local x axis. A positive <i>Psi</i> forms a right hand screw with the s axis."
Svphi	Elevation (dip) angle in radians. "The angle between the reference orbit and its projection onto the (Z, X) plane. If only horizontal bends are involved, the reference orbit remains in the (Z, X) plane. For this case, <i>Phi</i> is always 0."
Svclen	Intended as a starting element length sum value, but currently set to zero.
Svslen	Intended as a starting arc length sum value, but currently set to zero.
File(8)	The name of a Survey formatted file, including any path modifiers, produced by a Survey command with the <i>Tape</i> attribute used. <i>File</i> is string form in quotes with up to 64 characters. This file is intended to be a source of survey information about some reference line which could be involved in the survey matching. For the present, this feature is not used. To be useful, it will need some rather complicated coding to deal with trial lattices that may have somewhat different configurations and element names than the reference one.

If the **FMatch Line** attribute is given, the six initial survey coordinates describe the spatial origin of the initial line as named on the attribute. The results of survey tracking over the initial line are fed as inputs into the (Use) line being matched. Otherwise the *Svx*, etc group describes the start of the line being matched, noted on the **USE** command.

3. The FSConstraint Command

A new command, **FSConstraint**, has been introduced to describe survey coordinate constraints. As for other MAD constraints, the constrained variables may be noted by the usual =, > or < operators, indicating equality or limits such as an acceptance window. This closely resembles the ordinary FConstraint command, with the survey coordinates replacing the orbit functions. Only those survey variables for which data are given are constrained. Weights are defaulted from the dictionary or internal tables if they are not given.

Place	A MAD place group describing a position, or range of positions along the orbit for which the constraints are to be applied.
Svx	A constraint form for the value or range of values which are to be satisfied at each position included within the <i>Place</i> attribute. This and the following five attributes refer to the same spatial coordinates or directions as noted for the FSurfit command above.
Svy, Svz	
Svtheta, Svpsi, Svphi	
Svclen	The total length in meters over individual elements of the lattice section. This is meaningful only at the end of a specific lattice element, and will give rather silly results if applied to a line segment.

Svslen	The total path length in meters of the beam through all elements of the lattice section. This too is meaningful only at the end of a specific lattice element.
Others(2)	Intended for names of additional survey related variables. MAD variable name format, of element name, attribute name, and any needed indices.
Othercs(2)	Intended for constraint form of values of the <i>Others</i> named variables.
Weights(10)	Weights to be applied to each of the above constraints. If a constraint value is given without the corresponding weight, a default will be supplied from the dictionary, or failing this, from an internal table. Weights are provided separately here, as the survey nominal tolerances are usually of the order of .001m, which differ markedly from the familiar optical defaults of 1., etc.

Optical tracking and the usual Match summary listings are not printed if only survey constraints are given.

4. Program Changes

The changes needed for the survey matching blend easily into the existing BNL MAD Fast Match object and tracking codes, involving perhaps a thousand or so lines of new or modified code, including the usual nervous cleanup. As C++ isn't involved, this is only a day's work to edit and get to run.

A Matsurfit_F section has been added to accept the initial survey coordinates given on **FSurfit** input statements. This section deals with the FSurfit command, and its corresponding data base object. Minor changes in the Cell_F and Match_F sections clear flags for the survey matching, and in Matini_F reset the initial survey values vector.

A ConstrS_F section has been added to process FSConstraint statements, and handle the corresponding class of survey constraint objects during the matching operations. It is mainly an edited copy of the ordinary Constr_F lattice function constraint section. Survey tracking is done only if at least one survey constraint is given.

All sections which initialize and carry out lattice tracking have been modified to include survey tracking when one or more survey constraints have been given. These include Matbgn_F, Matend_F, Matin_F, Penbgn_F, and Penlty_F routines. A new routine Matsurvey_F has been added to do survey tracking for Penbgn_F when initial survey values are to be taken from a previously computed line. The current library of constraints, and the Migrad_F and Simplx_F search routines have not had to be changed.

5. Example

A sample set of survey matching commands, and the corresponding survey match run results are given at the end. The matching group setup is basically the same as for ordinary optics matching. In this BTA case, a trial line has been substituted in the region between quad QH4 near the Booster and bend DH5 near the AGS. The initial bending has been split into four equally spaced identical bends, separated by alternating H and V quads. The bending angle is adjusted to bring the line into the center of bend DH5 near the entrance to the AGS. A second run, not shown here, then adjusts the DH5 bend in

similar fashion.

The use of FConstraint and FVary lists with the FMatch command is included in this example. (Xmenu lists) In a problem such as the BTA which has many parameters to be matched to the numerous constraints during each of a number of trials, the editing situation soon gets out of hand as these command groups are moved in and out of the FMatch Fendmatch clusters. Instead libraries of stored FConstraint and FVary commands are maintained, with each command identified by a unique name. The set of constraints and variables to be currently applied is then simply noted by including the names in lists. As the various trials progress, selected lists of names can be used to distinguish among trials, and hopefully some sense of order is obtained. The collections of commands also serve as history files, from which individual members can be recalled. Under this style, editing of constraint and parameter sets is reduced to shuffling names of commands in lists.

6. Comments

A somewhat different approach to survey matching has been given by H. Grote in *MAD Survey Matching*, SL Note 95-56(AP) (CERN). July, 1995 It takes its comparison coordinates from a previously computed Survey file as reference, and expresses its constraints in terms of distances from that reference survey. It is oriented towards the problem of positioning a second ring around a first, with emphasis on maintaining separations and path lengths within restricted spaces. In principle it could be used here for BTA trial lattices with the present BTA survey as reference, constraining bend angles and spacings to match an existing entrance constraint condition to the AGS. Sadly, this involves time consuming mixing among program versions for a problem that has already involved major tailoring of our multi parameter search routines to deal better with local conditions. For now it has seemed easier to embed a few simple survey match features into our visually oriented BNL MAD than to jump between programs to get graphics.

The initial condition command does the same thing for the two versions, so we have used a minor variant of the CERN keyword definition, Surfit. The constraints are expressed rather differently, so we have used a keyword definition based on the ordinary Constraint command that it resembles.

Documents

Unix Typesetter Format - troff / psroff Files.

Host	rapt.ags.bnl.gov
This Report	/usr/disc2/jn/Docum+/Fmatch.man2
FMatch	/usr/disc2/jn/Docum+/Fmatch.man

To Print from rapt: (To Room 218 AGS 2nd Floor)

```
alias it. 'cat * | psroff -t -ms > ppp; lp ppp'
```

it. Manual Name

```
!      Example Command File for Survey Matching of BTA.
!*****
!      Nominal Older Entry Set from Booster.      July 1.96
      BETAX0_1  Param = 13.101 ;      ALFAX0_1  Param = 1.851
      BETAY0_1  Param = 3.87 ;      ALFAY0_1  Param = -.596
      DX_0_1    Param = 2.85 ;      DPX_0_1    Param = -.427
      Pdeltā    Param = 0.
!*****
!      Match Section for JBTA - Trail Lattice.      Vary Four Bend Angles.
!      Survey Constraints - "Library"
      Store
      !      Center of DH5 - Original Survey.
      SV_DH5a   FSconst   Place = DH5a,   Svz = - 17.309210
      SV_DRL20  FSconst   Place = DRL20b, Svz = - 20.124342,      &
      Svtheta = -.462420
      Endstore
!      List of Constraints, Selected from "Constraint Library".
      SV_list5   Xmenu = SV_DH5a

!      Vary Commands - "Library"
      Store
      VS_B2adj   Fvary,    B2adjust,      Step = .002,      &
      Lower = 1.02,      Upper = 1.081
      VS_B5adj   Fvary,    B5adjust,      Step = .005,      &
      Lower = 1.10,      Upper = 1.201
      Endstore
!      List of Vary Commands, Selected from "Vary Library".
      VS_list5   Xmenu = VS_B2adj
!*****
!      Match Command Library.
      Store
      FMI        Fmigrad,   Calls = 2000, TOLERANC = 1.E-8
      FSI        Fsimplex,   Calls = 500, TOLERANC = 1.E-13, Revised
      FMA_5S     Fmatch,    deltāp = pdeltā,      Second,      &
      Varlist = VS_list5,   Conlist = SV_list5,      &
      BETX       = Betax0_1, ALFX       = Alfax0_1,      &
      BETY       = Betay0_1, ALFY       = Alfay0_1,      &
      DX         = Dx_0_1,   DPX        = Dpx_0_1
      FTW.5      Ftwiss,    deltāp = pdeltā,      &
      BETX       = Betax0_1, ALFX       = Alfax0_1,      &
      BETY       = Betay0_1, ALFY       = Alfay0_1,      &
      DX         = Dx_0_1,   DPX        = Dpx_0_1
      Endstore
!*****
!      Use AGS Landscape Printing Format - 160 Columns.
      Setopts, Wide
      Use JBTA
!      Fmatch Group
      FMA_5s
      FSURfit    Svz = 0.,   Svy = 0.,   Svz = 0.
      FSI
      Fendmatch  -Verbose,   File = "Matchlist.bta"

!      Ftwiss Run with Match Results.
      Print JBTA
      FTW.5

      Return

      STOP
```

!! Matching on BTA Trial Lattice J. Adjust Bend Angle.

... BEGIN INSERTION MATCHING MODE.

Start of Simplex 2 Minimization, Tolerance = 1.00E-13

PENALTY FCT.	CALL	TIME	E.D.M.	PARAMETER NAME	PAR. VALUE	PAR. ERROR
8.366891E+05	1	0.000	1.000E+25	B2ADJUST	1.000000E+00	2.000000E-03

PENALTY FCT.	CALL	TIME	E.D.M.	PARAMETER NAME	PAR. VALUE	PAR. ERROR
1.050875E+04	6	0.000	2.573E+05	B2ADJUST	1.041006E+00	2.100600E-02

Simplex2_F: Minimization Has Converged

PENALTY FCT.	CALL	TIME	E.D.M.	PARAMETER NAME	PAR. VALUE	PAR. ERROR
1.601990E-15	71	2.000	1.554E-15	B2ADJUST	1.046213E+00	4.890754E-12

Region about Simplex Fit.

Original Values, Fitted Values. Increment / Value / Penalty											
1	B2ADJUST	0.104621E+01	0.100000E+01								
-0.200000E-02	-0.100000E-02	-0.600000E-03	-0.400000E-03	-0.200000E-03	0.000000E+00	0.200000E-03	0.400000E-03	0.600000E-03	0.100000E-02	0.200000E-02	
0.104421E+01	0.104521E+01	0.104561E+01	0.104581E+01	0.104601E+01	0.104621E+01	0.104641E+01	0.104661E+01	0.104681E+01	0.104721E+01	0.104821E+01	
0.154877E+04	0.387089E+03	0.139337E+03	0.619242E+02	0.154802E+02	0.160199E-14	0.154785E+02	0.619108E+02	0.139292E+03	0.386879E+03	0.154710E+04	

... End of "Simplex_F" Command, Elapsed Cpu Time = 2.4433 0.0283 Seconds

1

"MAD" VERSION: 7.63-BNL/UNI RUN: 08/28/96 14:29:40

MATCHING SUMMARY FOR BEAM LINE "JBTA", RANGE = "#S / #E"

POS. NO.	ELEMENT NAME	OCC. NO.	DIST M	CONDITION TYPE	QUANTITY NAME	WEIGHT	ACTUAL VALUE	MINIMUM VALUE	MAXIMUM VALUE	PENALTY CONTRIBUTION
75	DH5A	1	57.120	Survey Constraints	SvX	1.000000E+03	-1.730921E+01	-1.730921E+01	0.000000E+00	1.601990E-15

Summary of Survey Matching

ELEMENT		SEQUENCE		POSITIONS				ANGLES				ELEMENT		LENGTH STRENGTH	
POS. NO.	NAME	SUM(L) M	ARC M	I I	X M	Y M	Z M	I I	THETA RAD	PHI RAD	PSI RAD	I I		M	
0	Begin	0.000000	0.000000		0.000000	0.000000	0.000000		0.000000	0.000000	0.000000				
91	End	65.032629	65.033342		-20.190216	0.000000	59.958642		-0.473823	0.000000	0.000000				

..... Last Value of the Penalty Function: 1.601990E-15

..... End Matching Mode.

LINEAR LATTICE PARAMETERS FOR BEAM LINE: "JBTA" , RANGE = "#S / #E"
 DELTA(P)/P = 0.000000 symm = F

PAGE 1

ELEMENT SEQUENCE			I			H O R I Z O N T A L						I			V E R T I C A L					ELEMENT	LENGTH	STRENGTH
POS.	ELEMENT	OCC.	DIST I	BETAX	ALFAX	MUX	X(CO)	PX(CO)	DX	DPX	I	BETAY	ALFAY	MUY	Y(CO)	PY(CO)	DY	DPY				
NO.	NAME	NO.	[M]	[M]	[1]	[2PI]	[MM]	[.001]	[M]	[1]	I	[M]	[1]	[2PI]	[MM]	[.001]	[M]	[1]				
BEGIN	JBTA	1	0.000	13.101	1.851	0.000	0.000	0.000	2.850-0.427	3.870	-0.596	0.000	0.000	0.000	0.000	0.000	0.000	0.000				
BEGIN	L0	1	0.000	13.101	1.851	0.000	0.000	0.000	2.850-0.427	3.870	-0.596	0.000	0.000	0.000	0.000	0.000	0.000	0.000				
	1 MQHF6	1	0.000	13.101	1.851	0.000	0.000	0.000	2.850-0.427	3.870	-0.596	0.000	0.000	0.000	0.000	0.000	0.000	0.000	MARKER	0.00000	0.0000	
	2 DRQF6	1	0.236	12.246	1.771	0.003	0.000	0.000	2.749-0.427	4.171	-0.679	0.009	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.23610	0.0000	
	3 DHF6A	1	1.486	8.297	1.348	0.023	0.000	0.000	2.160-0.507	6.415	-1.090	0.048	0.000	0.000	0.000	0.000	0.000	0.000	SBEND	1.25000	-0.0715	
	4 DRF6A1	1	1.506	8.244	1.341	0.023	0.000	0.000	2.150-0.507	6.458	-1.097	0.049	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.01975	0.0000	
	5 DHF6T	1	1.506	8.244	1.341	0.023	0.000	0.000	2.150-0.507	6.458	-1.097	0.049	0.000	0.000	0.000	0.000	0.000	0.000	HKICK	0.00000	0.0000	
	6 DRF6A2	1	1.526	8.191	1.335	0.023	0.000	0.000	2.140-0.507	6.501	-1.104	0.049	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.01975	0.0000	
	7 DHF6B	1	2.853	5.251	0.885	0.056	0.000	0.000	1.425-0.572	9.999	-1.531	0.075	0.000	0.000	0.000	0.000	0.000	0.000	SBEND	1.32690	-0.0594	
	8 DRF6B	1	3.259	4.588	0.747	0.069	0.000	0.000	1.193-0.572	11.299	-1.666	0.082	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.40640	0.0000	
END	L0	1	3.259	4.588	0.747	0.069	0.000	0.000	1.193-0.572	11.299	-1.666	0.082	0.000	0.000	0.000	0.000	0.000	0.000				
BEGIN	L1	1	3.259	4.588	0.747	0.069	0.000	0.000	1.193-0.572	11.299	-1.666	0.082	0.000	0.000	0.000	0.000	0.000	0.000				
	9 PUEH001	1	3.259	4.588	0.747	0.069	0.000	0.000	1.193-0.572	11.299	-1.666	0.082	0.000	0.000	0.000	0.000	0.000	0.000	MONITOR	0.00000	0.0000	
	10 DR001	1	4.344	3.368	0.378	0.114	0.000	0.000	0.573-0.572	15.308	-2.029	0.095	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	1.08490	0.0000	
	11 MW006	1	4.344	3.368	0.378	0.114	0.000	0.000	0.573-0.572	15.308	-2.029	0.095	0.000	0.000	0.000	0.000	0.000	0.000	MARKER	0.00000	0.0000	
	12 DR006	1	4.776	3.104	0.231	0.135	0.000	0.000	0.326-0.572	17.126	-2.174	0.099	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.43260	0.0000	
	13 DV007	1	5.005	3.016	0.154	0.147	0.000	0.000	0.195-0.572	18.138	-2.250	0.101	0.000	0.000	0.000	0.000	0.000	0.000	VKICK	0.22860	0.0000	
	14 DR007	1	5.166	2.975	0.099	0.155	0.000	0.000	0.103-0.572	18.869	-2.304	0.102	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.16060	0.0000	
	15 QV1	1	5.724	3.634	-1.361	0.184	0.000	0.000	-0.216-0.592	17.486	4.601	0.107	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.55880	-0.6754	
	16 DRQ1	1	6.128	4.859	-1.677	0.199	0.000	0.000	-0.455-0.592	13.982	4.090	0.111	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.40315	0.0000	
	17 DH1	1	6.661	6.870	-2.095	0.214	0.000	0.000	-0.760-0.553	9.965	3.438	0.118	0.000	0.000	0.000	0.000	0.000	0.000	RBEND	0.53330	0.0364	
END	L1	1	6.661	6.870	-2.095	0.214	0.000	0.000	-0.760-0.553	9.965	3.438	0.118	0.000	0.000	0.000	0.000	0.000	0.000				
BEGIN	JJ2	1	6.661	6.870	-2.095	0.214	0.000	0.000	-0.760-0.553	9.965	3.438	0.118	0.000	0.000	0.000	0.000	0.000	0.000				
	18 DRD1	1	7.040	8.573	-2.393	0.221	0.000	0.000	-0.970-0.553	7.541	2.950	0.125	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.37935	0.0000	
	19 QH2A	1	7.599	8.731	2.138	0.231	0.000	0.000	-1.127 0.004	6.414	-0.742	0.139	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.55880	0.9271	
	20 DRQ2A	1	7.715	8.245	2.064	0.233	0.000	0.000	-1.127 0.004	6.590	-0.770	0.142	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.11580	0.0000	
	21 QH2B	1	8.274	4.374	4.182	0.248	0.000	0.000	-0.965 0.559	9.808	-5.535	0.153	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.55880	0.9271	
	22 DRQ2B	1	8.734	1.422	2.238	0.277	0.000	0.000	-0.708 0.559	15.582	-7.019	0.159	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.45990	0.0000	
	23 XF019	1	8.734	1.422	2.238	0.277	0.000	0.000	-0.708 0.559	15.582	-7.019	0.159	0.000	0.000	0.000	0.000	0.000	0.000	MARKER	0.00000	0.0000	
	24 DR019A	1	9.324	0.252	-0.256	0.500	0.000	0.000	-0.378 0.559	24.990	-8.923	0.164	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.59020	0.0000	
	25 QV3	1	9.883	2.231	-3.734	0.646	0.000	0.000	-0.121 0.391	24.909	9.049	0.167	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.55880	-1.2484	
	26 DRQ3A	1	9.989	3.099	-4.445	0.653	0.000	0.000	-0.079 0.391	23.026	8.696	0.168	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.10610	0.0000	
	27 FOIL024	1	9.989	3.099	-4.445	0.653	0.000	0.000	-0.079 0.391	23.026	8.696	0.168	0.000	0.000	0.000	0.000	0.000	0.000	MARKER	0.00000	0.0000	
	28 DR024	1	10.933	17.459	-10.767	0.673	0.000	0.000	0.290 0.391	9.573	5.555	0.178	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.94400	0.0000	
END	JJ2	1	10.933	17.459	-10.767	0.673	0.000	0.000	0.290 0.391	9.573	5.555	0.178	0.000	0.000	0.000	0.000	0.000	0.000				
BEGIN	JJ3	1	10.933	17.459	-10.767	0.673	0.000	0.000	0.290 0.391	9.573	5.555	0.178	0.000	0.000	0.000	0.000	0.000	0.000				
	29 QH4	1	11.491	20.328	6.512	0.677	0.000	0.000	0.422 0.061	7.913	-2.108	0.189	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.55880	1.5901	
	30 JDQH4	1	12.091	13.282	5.231	0.683	0.000	0.000	0.458 0.061	10.690	-2.520	0.200	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000	
	31 NBH2A	1	13.301	3.739	2.664	0.711	0.000	0.000	0.626 0.217	17.592	-3.143	0.214	0.000	0.000	0.000	0.000	0.000	0.000	SBEND	1.21000	0.1442	
	32 JDH2A	1	13.901	1.321	1.365	0.754	0.000	0.000	0.757 0.217	21.587	-3.514	0.219	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000	
	33 NQV4	1	14.400	0.593	0.168	0.852	0.000	0.000	0.924 0.463	21.878	2.960	0.222	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	-0.5925	
	34 JDQV4	1	15.000	1.016	-0.873	0.993	0.000	0.000	1.202 0.463	18.487	2.692	0.227	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000	
	35 NBH2B	1	16.210	5.633	-2.947	1.077	0.000	0.000	1.852 0.615	12.403	2.300	0.240	0.000	0.000	0.000	0.000	0.000	0.000	SBEND	1.21000	0.1442	
	36 JDH2B	1	16.810	9.788	-3.979	1.090	0.000	0.000	2.221 0.615	9.825	1.996	0.248	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000	
	37 NQH5	1	17.308	11.580	0.654	1.097	0.000	0.000	2.275-0.402	10.005	-2.382	0.257	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	0.8909	
	38 JDQH5	1	17.908	10.840	0.580	1.105	0.000	0.000	2.034-0.402	13.103	-2.782	0.265	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000	
	39 NBH3A	1	19.118	9.573	0.468	1.124	0.000	0.000	1.639-0.251	20.570	-3.344	0.277	0.000	0.000	0.000	0.000	0.000	0.000	SBEND	1.21000	0.1442	
	40 JDH3A	1	19.718	9.057	0.392	1.135	0.000	0.000	1.489-0.251	24.796	-3.699	0.281	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000	

ELEMENT SEQUENCE			H O R I Z O N T A L										V E R T I C A L						ELEMENT	LENGTH	STRENGTH
POS.	ELEMENT	NO.	DIST I	BETAX	ALFAX	MUX	X(CO)	PX(CO)	DX	DPX	I	BETAY	ALFAY	MUY	Y(CO)	PY(CO)	DY	DPY			
NO.	NAME	NO.	[M]	[M]	[1]	[2PI]	[MM]	[.001]	[M]	[1]	I	[M]	[1]	[2PI]	[MM]	[.001]	[M]	[1]			
	41 NQV5	1	20.217	9.981	-2.330	1.143	0.000	0.000	1.465	0.156		25.002	3.305	0.284	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	-0.5594
	42 JDQV5	1	20.817	13.010	-2.717	1.151	0.000	0.000	1.559	0.156		21.208	3.019	0.288	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000
	43 NBH3B	1	22.027	20.424	-3.417	1.163	0.000	0.000	1.839	0.308		14.343	2.613	0.299	0.000	0.000	0.000	0.000	SBEND	1.21000	0.1442
	44 JDH3B	1	22.627	24.748	-3.789	1.167	0.000	0.000	2.024	0.308		11.403	2.286	0.307	0.000	0.000	0.000	0.000	DRIFT	0.60000	0.0000
	45 NQH6	1	23.125	24.986	3.336	1.171	0.000	0.000	2.032-0.275	10.737	-0.887	0.314	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	0.5696
END	JJ3	1	23.125	24.986	3.336	1.171	0.000	0.000	2.032-0.275	10.737	-0.887	0.314	0.000	0.000	0.000	0.000	0.000	0.000			
BEGIN	JJ4	1	23.125	24.986	3.336	1.171	0.000	0.000	2.032-0.275	10.737	-0.887	0.314	0.000	0.000	0.000	0.000	0.000	0.000			
	46 JDQH6	1	26.036	9.680	1.923	1.201	0.000	0.000	1.232-0.275	17.311	-1.372	0.348	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
	47 NQV7	1	26.534	8.191	1.099	1.210	0.000	0.000	1.117-0.190	18.071	-0.134	0.353	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	-0.1449
	48 JDQV7	1	29.445	4.076	0.315	1.294	0.000	0.000	0.563-0.190	19.330	-0.298	0.378	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
	49 NQH8	1	29.943	3.821	0.196	1.314	0.000	0.000	0.468-0.192	19.683	-0.410	0.382	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	0.0085
	50 JDQH8	1	32.854	4.981	-0.595	1.430	0.000	0.000	-0.093-0.192	22.571	-0.583	0.404	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
	51 NQV8	1	33.352	6.134	-1.786	1.445	0.000	0.000	-0.194-0.218	21.189	3.271	0.407	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	-0.3568
	52 JDQH8A	1	34.541	11.345	-2.598	1.467	0.000	0.000	-0.453-0.218	14.193	2.615	0.418	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	1.18858	0.0000
	53 DH4	1	35.074	14.310	-2.963	1.474	0.000	0.000	-0.564-0.199	11.558	2.327	0.425	0.000	0.000	0.000	0.000	0.000	0.000	RBEND	0.53330	0.0171
	54 JDQH8B	1	36.263	22.318	-3.775	1.485	0.000	0.000	-0.801-0.199	6.811	1.667	0.446	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	1.18858	0.0000
END	JJ4	1	36.263	22.318	-3.775	1.485	0.000	0.000	-0.801-0.199	6.811	1.667	0.446	0.000	0.000	0.000	0.000	0.000	0.000			
BEGIN	JJ5A	1	36.263	22.318	-3.775	1.485	0.000	0.000	-0.801-0.199	6.811	1.667	0.446	0.000	0.000	0.000	0.000	0.000	0.000			
	55 NQH9	1	36.761	22.536	3.360	1.488	0.000	0.000	-0.835 0.062	6.241	-0.465	0.459	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	0.6318
	56 JDQH9	1	39.672	7.596	1.773	1.524	0.000	0.000	-0.655 0.062	10.596	-1.032	0.517	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
	57 NQV9	1	40.170	6.455	0.574	1.535	0.000	0.000	-0.648-0.034	10.858	0.519	0.524	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	-0.2974
	58 JDQV9	1	43.081	4.860	-0.026	1.622	0.000	0.000	-0.747-0.034	8.826	0.179	0.572	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
	59 NQH10	1	43.579	4.614	0.509	1.639	0.000	0.000	-0.738 0.067	9.279	-1.108	0.581	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	0.2718
	60 JDQH10	1	46.490	3.963	-0.285	1.758	0.000	0.000	-0.543 0.067	17.760	-1.806	0.618	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
	61 NQV11	1	46.988	4.997	-1.895	1.776	0.000	0.000	-0.551-0.101	16.819	3.595	0.622	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	-0.6248
	62 JDQV11	1	49.899	23.815	-4.570	1.819	0.000	0.000	-0.845-0.101	2.905	1.185	0.690	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
	63 NQH12	1	50.397	24.969	2.365	1.822	0.000	0.000	-0.835 0.140	2.254	0.182	0.722	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	0.5675
	64 JDQH12	1	53.307	13.439	1.596	1.848	0.000	0.000	-0.429 0.140	5.078	-1.152	0.887	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	2.91045	0.0000
END	JJ5A	1	53.307	13.439	1.596	1.848	0.000	0.000	-0.429 0.140	5.078	-1.152	0.887	0.000	0.000	0.000	0.000	0.000	0.000			
BEGIN	JJ5B	1	53.307	13.439	1.596	1.848	0.000	0.000	-0.429 0.140	5.078	-1.152	0.887	0.000	0.000	0.000	0.000	0.000	0.000			
	65 QV13	1	53.806	13.905	-2.577	1.854	0.000	0.000	-0.391 0.016	5.487	0.375	0.902	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	-0.6134
	66 DRQ13	1	54.403	17.177	-2.905	1.860	0.000	0.000	-0.382 0.016	5.113	0.251	0.920	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.59695	0.0000
	67 MW166	1	54.403	17.177	-2.905	1.860	0.000	0.000	-0.382 0.016	5.113	0.251	0.920	0.000	0.000	0.000	0.000	0.000	0.000	MARKER	0.00000	0.0000
	68 DR166	1	54.833	19.780	-3.141	1.864	0.000	0.000	-0.375 0.016	4.935	0.162	0.934	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.43050	0.0000
	69 DV168	1	55.077	21.344	-3.275	1.865	0.000	0.000	-0.371 0.016	4.869	0.111	0.941	0.000	0.000	0.000	0.000	0.000	0.000	VKICK	0.24380	0.0000
	70 DR168	1	55.374	23.334	-3.438	1.868	0.000	0.000	-0.366 0.016	4.821	0.049	0.951	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.29640	0.0000
	71 PUEH170	1	55.374	23.334	-3.438	1.868	0.000	0.000	-0.366 0.016	4.821	0.049	0.951	0.000	0.000	0.000	0.000	0.000	0.000	MONITOR	0.00000	0.0000
	72 DR170	1	55.492	24.156	-3.503	1.868	0.000	0.000	-0.364 0.016	4.812	0.025	0.955	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.11835	0.0000
	73 QH14	1	55.990	24.643	2.566	1.872	0.000	0.000	-0.335 0.103	5.457	-1.371	0.971	0.000	0.000	0.000	0.000	0.000	0.000	QUADRUPO	0.49850	0.4959
	74 DRQ14	1	56.497	22.122	2.410	1.875	0.000	0.000	-0.282 0.103	6.983	-1.639	0.984	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.50675	0.0000
	75 DH5A	1	57.120	19.242	2.219	1.880	0.000	0.000	-0.245 0.018	9.181	-1.880	0.996	0.000	0.000	0.000	0.000	0.000	0.000	RBEND	0.62280	-0.0774
	76 DH5B	1	57.743	16.600	2.027	1.885	0.000	0.000	-0.260-0.067	11.652	-2.076	1.006	0.000	0.000	0.000	0.000	0.000	0.000	RBEND	0.62280	-0.0774
END	JJ5B	1	57.743	16.600	2.027	1.885	0.000	0.000	-0.260-0.067	11.652	-2.076	1.006	0.000	0.000	0.000	0.000	0.000	0.000			
BEGIN	L6	1	57.743	16.600	2.027	1.885	0.000	0.000	-0.260-0.067	11.652	-2.076	1.006	0.000	0.000	0.000	0.000	0.000	0.000			
	77 DRD5	1	58.194	14.832	1.888	1.890	0.000	0.000	-0.290-0.067	13.620	-2.282	1.012	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.45160	0.0000
	78 DV181	1	58.438	13.930	1.813	1.893	0.000	0.000	-0.306-0.067	14.759	-2.393	1.014	0.000	0.000	0.000	0.000	0.000	0.000	VKICK	0.24380	0.0000
	79 DR181	1	58.818	12.597	1.696	1.897	0.000	0.000	-0.332-0.067	16.642	-2.566	1.018	0.000	0.000	0.000	0.000	0.000	0.000	DRIFT	0.37980	0.0000
	80 XF183	1	58.818	12.597	1.696	1.897	0.000	0.000	-0.332-0.067	16.642	-2.566	1.018	0.000	0.000	0.000	0.000	0.000	0.000	MARKER	0.00000	0.0000

LINEAR LATTICE PARAMETERS FOR BEAM LINE: "JBTA" " , RANGE = "#S / #E"

DELTA(P)/P = 0.000000 symm = F

PAGE 3

ELEMENT SEQUENCE			H O R I Z O N T A L										V E R T I C A L							ELEMENT	LENGTH	STRENGTH
POS. NO.	ELEMENT NAME	OCC. NO.	DIST I [M]	BETAX [M]	ALFAX [1]	MUX [2PI]	X(CO) [MM]	PX(CO) [.001]	DX [M]	DPX [1]	BETAY [M]	ALFAY [1]	MUY [2PI]	Y(CO) [MM]	PY(CO) [.001]	DY [M]	DPY [1]					
	81 DR183	1	59.344	10.899	1.534	1.904	0.000	0.000	-0.367	-0.067	19.465	-2.805	1.023	0.000	0.000	0.000	0.000	DRIFT	0.52550	0.0000		
	82 QV15	1	59.902	10.440	-0.682	1.913	0.000	0.000	-0.426	-0.147	20.370	1.247	1.027	0.000	0.000	0.000	0.000	QUADRUPO	0.55880	-0.3647		
	83 DRQ15	1	60.139	10.770	-0.715	1.916	0.000	0.000	-0.461	-0.147	19.788	1.217	1.029	0.000	0.000	0.000	0.000	DRIFT	0.23630	0.0000		
	84 SHOLE	1	60.139	10.770	-0.715	1.916	0.000	0.000	-0.461	-0.147	19.788	1.217	1.029	0.000	0.000	0.000	0.000	MARKER	0.00000	0.0000		
END	L6	1	60.139	10.770	-0.715	1.916	0.000	0.000	-0.461	-0.147	19.788	1.217	1.029	0.000	0.000	0.000	0.000					
BEGIN	L7	1	60.139	10.770	-0.715	1.916	0.000	0.000	-0.461	-0.147	19.788	1.217	1.029	0.000	0.000	0.000	0.000					
	85 DRQ15B	1	62.401	14.723	-1.032	1.945	0.000	0.000	-0.793	-0.147	14.923	0.934	1.050	0.000	0.000	0.000	0.000	DRIFT	2.26190	0.0000		
	86 L20SPTM1	1	63.466	17.080	-1.182	1.956	0.000	0.000	-0.911	-0.075	13.016	0.852	1.062	0.000	0.000	0.000	0.000	RBEND	1.06514	0.0655		
	87 DRL20A1	1	63.496	17.150	-1.186	1.956	0.000	0.000	-0.913	-0.075	12.966	0.848	1.063	0.000	0.000	0.000	0.000	DRIFT	0.02987	0.0000		
	88 L20SPTMT	1	63.496	17.150	-1.186	1.956	0.000	0.000	-0.913	-0.075	12.966	0.848	1.063	0.000	0.000	0.000	0.000	HKICK	0.00000	0.0000		
	89 DRL20A2	1	63.525	17.221	-1.190	1.956	0.000	0.000	-0.915	-0.075	12.915	0.844	1.063	0.000	0.000	0.000	0.000	DRIFT	0.02987	0.0000		
	90 L20SPTM2	1	64.560	19.832	-1.335	1.965	0.000	0.000	-0.957	-0.005	11.261	0.751	1.077	0.000	0.000	0.000	0.000	RBEND	1.03454	0.0637		
	91 DRL20B	1	65.033	21.126	-1.402	1.969	0.000	0.000	-0.959	-0.005	10.582	0.685	1.084	0.000	0.000	0.000	0.000	DRIFT	0.47272	0.0000		
END	L7	1	65.033	21.126	-1.402	1.969	0.000	0.000	-0.959	-0.005	10.582	0.685	1.084	0.000	0.000	0.000	0.000					
END	JBTA	1	65.033	21.126	-1.402	1.969	0.000	0.000	-0.959	-0.005	10.582	0.685	1.084	0.000	0.000	0.000	0.000					
TOTAL LENGTH =			65.032629			MUX		=	1.968994			MUY		=	1.083719							
DELTA(S) =			0.000000 mm			DMUX		=	-6.104422			DMUY		=	-1.196639							
						BETAX (MAX)		=	24.985518			BETAY (MAX)		=	25.002394							
						DX (MAX)		=	2.850000			DY (MAX)		=	0.000000							