PRE-USE INSPECTION CHECK LIST MANUALLY PROPELLED ELEVATION WORK PLATFORMS - VERTICAL MAST

ANSI A92.3 Manually Propelled Elevating Aerial Platforms

CATEGORY	ACTION	RESULTS
Inspections	Annual Inspection Current Frequent Inspection (3 month) Current Pre-Use Inspection Tag	
Manuals	Review & Verify Manufacture's Operating and Safety Manual and ANSI Manual of Responsibilities are enclosed in weather resistant storage container	
Cleanliness	 Check that all surfaces are free of leakage from: Hydraulic Oil Battery fluid 	
Cleanliness	No Foreign Object found around base or moving parts	
Decals/Placards	 All decals and placards legible See Manufacture's manual for locations 	
Walk around	 Check the following: Wheels are free of debris and tires pressurized Outriggers in good condition and level functional No loose wires or cables dangling from base frame Visual check that fluid levels are to the full line Breather Cap on Hydraulic Reservoir installed Batteries charged, cables secured, free of corrosion Platform Assembly and Gate / latch hardware and pins in place and secured Mast Assembly and components in good condition, cables/chains taut and seated in sheaves Ground Control Station selector switch, operational, Emergency Stop (E-Stop) Switch operational and reset of operation, control markings legible Fall Restrain Anchorages identified and in good condition 	
Functional Check	 Ground Control Checks (per Manufacture's manual): Control console is mounted & secure E-Stop Switch functional (depress E-stop and ensure that no control functions are working) Auxiliary platform lowering via the Control activate Button Lowering using Manual Lower Valve 	
Functional Check	 Platform Control Checks (per Manufacture's manual): Control console is mounted & secure E-Stop Switch functional (depress E-stop and ensure that no control functions are working) Check Interlock display lights Auxiliary platform lowering button using the Control activate Button 	

PRE-USE INSPECTION CHECK LIST MANUALLY PROPELLED ELEVATION WORK PLATFORMS - VERTICAL MAST

ANSI A92.3 Manually Propelled Elevating Aerial Platforms

CATEGORY	ACTION	RESULTS	
OPTIONS			
Functional	Outrigger Interlock (if applicable)		
Check	For each outrigger,		
	Release E Stop button at Platform Control		
	Check up/down function operational		
	• Unscrew test leveling jack (only one at a time)		
	• Verify LED Indicator lights up/down function not operational		
	Return jack to correct position		
	• Repeat for remaining outriggers		
Sign Off	If unit is operational, initial and date; Pre-Use Inspection		
	Record Tag.		
	Note: If safety deficiencies are noted: Yellow Tag unit Out		
	of Service and inform supervisor.		