


PRE-USE INSPECTION CHECK LIST
FOR USE ON SELF-PROPELLED ELEVATION WORK PLATFORMS - BOOM STYLE
ANSI A92.5 Boom Supported Elevating Work Platform

CATEGORY	ACTION	RESULTS
Inspections	Annual Inspection Current Frequent Inspection (3 month) Current <i>Includes Oscillating Axle Lockout test (if applicable)</i> Pre-Use Inspection Tag	<input type="checkbox"/>
Manuals	Review & Verify Manufacture's Operating and Safety Manual and ANSI Manual of Responsibilities are enclosed in weather resistant storage container	<input type="checkbox"/>
Cleanliness	Check that all surfaces are free of leakage from: <ul style="list-style-type: none"> • Hydraulic Oil • Fuel (if applicable) • Battery fluid 	<input type="checkbox"/>
Cleanliness	No Foreign Object found around base or moving parts No weld cracks	<input type="checkbox"/>
Decals/Placards	All decals and placards legible <ul style="list-style-type: none"> • See Manufacture's manual for locations 	<input type="checkbox"/>
Walk around	Check the following: <ul style="list-style-type: none"> • Drive and Caster Wheels are free of debris • Lug nuts: none missing, properly installed • Rotator Cylinders free of debris and no leaks • Hydraulic Pump & Reservoir: Secured, no leaks • Visual check that fluid levels are to the full line and caps are secured • Batteries charged, cables secured, free of corrosion • Cowling and latches: No missing hardware & secured • Ground Control Station selector switch, operational, Emergency Stop (E-Stop) Switch operational • Static Straps: Installed (if applicable) • Counterweight: Secure, no missing parts/visual damage • Boom: No cracks, dents or burn marks • No loose or chafed wires or cables (chafing protection installed) • All pins installed and locked • Platform Assembly and Gate/Chain hardware and pins in place and secured • Platform Control E-Stop Switch operational and reset of operation • Fall Restraint Anchorages identified and in good condition Platform Touch Indicators operational and in good condition (if applicable) 	<input type="checkbox"/>
Functional Check (See Manual for details)	Ground Control Checks (per Manufacture's manual): <ul style="list-style-type: none"> • Control functions operational • E-Stop Switch functional 	<input type="checkbox"/>

PRE-USE INSPECTION CHECK LIST
FOR USE ON SELF-PROPELLED ELEVATION WORK PLATFORMS - BOOM STYLE
ANSI A92.5 Boom Supported Elevating Work Platform

CATEGORY	ACTION	RESULTS
Functional Check (See Manual for details)	Platform Control Checks (per Manufacture's manual): <ul style="list-style-type: none"> • Control console is mounted & secure • Check control function switch guards are functional • E-Stop Switch functional • Control functional operational (raise/lower 2-ft) • Machine Brake check • Drive Speed Reduction Limit 	<input type="checkbox"/>
OPTIONS		
Functional Check (See Manual for details)	Tilt System (if applicable) <ul style="list-style-type: none"> • If the lift is to be used with the potential of being on uneven surfaces, verify Tilt Control. (energize ground station, with no one in the platform raise platform a few feet) locating the level sensor and manually moving it out of position. Alarm should sound and platform lift should cut-out. 	<input type="checkbox"/>
Functional Check (See Manual for details)	Oscillating Axle & Lockout System (if applicable) <ul style="list-style-type: none"> • Verify lockout valve plunger in depressed position • Swing turntable until axle lockout bracket passed the plunger and verify plunger is fully extended <p style="text-align: center;"><u>Example System</u></p>  <p style="text-align: center;">CAUTION</p>	<input type="checkbox"/>
Sign Off	If unit is operational, initial and date; Pre-Use Inspection Record Tag Note: If safety deficiencies are noted: Yellow Tag unit Out of Service and inform supervisor	<input type="checkbox"/>