

RHIC Machine Status

Angelika Drees



RHIC AGS User Group Meeting
23 January 2004

Content

- Run-4 start-up and ramp-up
- Run-4 Luminosity development
- Current typical running conditions
- Improvements
- Luminosity limitations
- Summary

Run- 4 star- up and ramp- up

- 12/01/03 2 weeks of start–up begin
(24h/day machine development)
- 12/15/03 2 weeks of ramp–up begin
(owl shift for experiments)
- 12/31/03 Physics Run started

Comments:


- Ramp–up period 1 week shorter than planned
- Total of 8 days with larger problems during start–up/ramp–up
- Started Physics Run with
 - stores above design luminosity
 - $\sim 40(\mu\text{b})^{-1}/\text{week}$ (last week in Run–2 had $24(\mu\text{b})^{-1}$)

[luminosity numbers denote delivery to Phenix/Star]


Run- 4 luminosity evolution

Delivered $182.5 (\mu\text{b})^{-1}$ to Phenix [109.8]
72.7 $(\mu\text{b})^{-1}$ last week [42.4]
Target 330 $(\mu\text{b})^{-1}$

Star $\times 0.9$
Phobos $\times 0.3$
Brahms $\times 0.5?$



Projected Run-4 Au–Au Luminosity Evolution



- Experimental target luminosity > 3x higher than achieved in last Au–Au run with the same time!

Run- 4 current typical running conditions

Sat 01/17/04 Current typical running conditions (under consideration at all times):

Quantity	Unit	Value	Comment
Bunch intensity	10^9 Au ions	1.0 / 0.7	Blue / Yellow, injected
Number of bunches	...	61	per ring
Initial ZDC rates	kHz	8.0	at Phenix and Star, 1/3 at Brahm's and Phobos
Initial luminosity	$10^{26} \text{ cm}^{-2} \text{ s}^{-1}$	8.0	at Phenix and Star, 1/3 at Brahm's and Phobos
Luminosity lifetime	hrs	2.5	for first 3 hours of store, larger thereafter
Time between fills	hrs	5.0	for uninterrupted production
Optimum store length	hrs	3.8	to maximize average luminosity, for uninterrupted production


Comments:

- initial luminosity is 8x design
- average store luminosity is ~2x design (good stores)
- luminosity lifetime is dominated by IBS and beam–beam (no collision beam lifetime about 20 hours)
- time between fills has large variations (0.5 to 12 hours)

Run- 4 improvements: luminosity

- Better optics model
- Orbit correction after each ramp
- Flexible bunch patterns
(almost all bunch numbers between 3 and 111, arbitrarily distributed)
- Better instrumentation
(IPM, Schottky, PLL tune meter, BPMs — still in progress)
- Low order nonlinear IR correction finished
- Continuous Gap Cleaning
- Better background reduction
 - Shielding for Phenix and Brahms
 - Horizontal 2-stage collimation in both rings
- Faster beginning-of-store activities
 - Automatic steering for all experiments ~5min
 - Automatic collimator settings (optimization still in progress)


New Collimation System



Steering and motion of collimators (total of 18 motion channels!) automated by **feedback** based on signals from PinDiodes (loss monitors).


Status: collimators installed, software development done, optimization in progress

New Collimator Performance




Reduction is in the order of x10 (have seen even better :))
times achieved: ~3 minutes
working on feedback using exp. background signals

Flexible Bunch Patterns




Use a combination of 60-bunch and 120-bunch fill patterns by injecting bunches into 3rd and 6th buckets. Total number of bunches is:
 $55 < 68 < 110$
 Increase is 20% per ring.

Gap Cleaning Performance




no gap cleaning

continuous gap cleaning



Automatic Steering (with LISA)



Timescale: ~ 5 minutes, maintains optimum rates for experiments

Run- 4 improvements: time in store

- More efficient operation
 - Faster down ramps
 - Faster quench recovery (refrigerator)
 - Higher loss limits on ramp (fewer ramps aborted)
 - Fast access from home (more analysis power available)
 - Phobos magnet controlled by Sequencer/MCR
- Increased reliability
 - AtR, starved microbes in cooling water
 - Much reduced ice ball maintenance
 - Corrector power supplies

FY04 Improvements and Status

- **Collimation** system upgrade and feedback (→ done)
- Upgraded **gap cleaning** technique (→ done)
- **Shielding** @ BRAHMS and PHENIX (→ done)
- flexible **bunch pattern** (→ done)
- online **modelling**, “bump” closure (→ done)
- **Vacuum** (→ part. done)
- Automated Luminosity **Steering** (LISA) (→ done)
- BPMs (reliability), Instrumentation (→ part. done)
- Hardware changes to reduce recovery and maintenance (quench protection, ice balls, fast down ramps) (→ done)
- Faster/more user friendly operations tools (ramp analysis, more automation) (→ done)

Luminosity limitations

- Vacuum
 - Yellow stochastic cooling kicker yo4, now baked
 - Blue collimators bi8
 - Blue instrumentation section bo2
- Intrabeam scattering
 - At injection:
 - Longitudinal emittance increase
 - Debunching
 - At store:
 - Debunching
 - Transverse emittance increase
- Beam–beam interaction
- Background

Luminosity lifetime: ~2.5hrs

Beam lifetime without collisions: ~20 hrs

Summary

- Run-4 start-up and ramp-up period one week shorter than planned
- Current gold-gold luminosity is about 2x higher than at end of last gold-gold run (instantaneous, per store and per week)
- Most improvements for gold-gold operation will also benefit polarized proton operation