

The only official copy of this file is the one on-line on the Superconducting Magnet Division website. Before using a printed copy, verify that this is the most current version by checking the document issue date on the website.

## SMD Operations Procedures Manual

### 8.1.3.13 OPERATION OF MODEL 4000 REFRIGERATOR (MAGCOOL REFRIGERATOR)

Text Pages 1 through 3

#### Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Revision No. 00

Approved:

\_\_\_\_\_  
Division Head

\_\_\_\_\_  
Date

The only official copy of this file is the one on-line on the Superconducting Magnet Division website. Before using a printed copy, verify that this is the most current version by checking the document issue date on the website.

### **8.1.3.13 Operation of Model 4000 Refrigerator (MAGCOOL Refrigerator)**

#### **1.0 Purpose**

This procedure provides instruction for STARTUP/SHUTDOWN and operation of the MAGCOOL Refrigerator Model 4000.

#### **2.0 Responsibilities and Scope**

Operator is responsible for STARTUP/SHUTDOWN and operation of the refrigerator.

#### **3.0 Prerequisites**

- 3.1 Operator shall be trained by a supervisor or an authorized operator.
- 3.2 Training shall include the Mycom compressor and the Test and Measure system on MAGCOOL Refrigerator (MODEL 4000).

#### **4.0 Precautions**

- 4.1 Hearing protection shall be worn in the Compressor Rooms and in the Refrigeration Room. (MODEL 4000).
- 4.2 Ensure only authorized personnel are near units to be operated.

#### **5.0 Procedure**

Refrigerator and Test and Measure System Cooldown. This process should be started when the magnet in Cooldown 1 approaches 100<sup>0</sup> K. As each step is completed, an entry to that effect should be made in the Logbook.

- 5.1 Set pressure controller to 220 psig.  
Start Mycom compressor.  
At Refrigerator set the following valves:
  - 5.1.1 Turn on LN<sub>2</sub>.
  - 5.1.2 PC-1 Controller in **MANUAL** and closed.
  - 5.1.3 PI/TC-1 Controller in **MANUAL** and closed.

**The only official copy of this file is the one on-line on the Superconducting Magnet Division website. Before using a printed copy, verify that this is the most current version by checking the document issue date on the website.**

- 5.1.4 PC-3 Controller in **MANUAL** and closed.
- 5.1.5 TC-1 Controller in **MANUAL** and open.
- 5.1.6 At CRT display pg. D23.
- 5.1.7 Close valves D22, D23 and D20.
- 5.1.8 Open valve D24.
- 5.1.9 Set "**ENABLE/RESET By-pass Valve Logic**" Flag **RED** move cursor to **RED PART OF FLAG** and **PRESS CLEAR** then **PRESS SET**.
- 5.1.10 The **FLAG** should be all **RED** and this means the computer logic will operate the refrigerator bypass valves.
- 5.7 Start gas flow through refrigerator and test and measure system.
  - 5.7.1 Crack open valve MOV 205.
  - 5.7.2 When pressure at PI1002 reaches 245 PSIA open valve fully.
  - 5.7.3 Remove jacks from engine.
  - 5.7.4 Start engines E-19 and E-20, set speed at 180 RPM.
  - 5.7.5 Manually crack open valve PI/TC-1 controller until pressure is 165 psi then switch controller to auto.
- 5.8 After system is cold and pre and sub cooler pots are full.
  - 5.8.1 Throttle E-19 and E-20 to approximately 120 to 150 rpm
  - 5.8.2 Shut one of the engines off.
- 5.9 You are now ready for operations.
  - 5.9.1 To Shut down MAGCOOL Refrigerator
    - A. Reduce interstage press to ~45 psig at Mycom. Reduce discharge press to ~225 psig.

**The only official copy of this file is the one on-line on the Superconducting Magnet Division website. Before using a printed copy, verify that this is the most current version by checking the document issue date on the website.**

- B. Close MOV 205- inlet to refrigerator, stop engines and let pressure drop to return pressure.
- C. Stop circulator before loop pressure reaches 2 atms.  
Bring cursor to **CIRCULATOR** flag, press **CLEAR**.
- D. Remove from **CIRCULATOR MODE**.  
**Bring cursor to CIRCULATOR MODE flag, press CLEAR.**
- E. Unload Mycom to ~50%. Leave enough capacity to handle pumpback of returning gas. When system is stable, unload and stop compressor.
- F. Shut LN<sub>2</sub> Valve N1001A

## **6.0 Documentation**

Documentation is kept in the MAGCOOL Logbook located in Building 902.

## **7.0 References**

- 7.1 Operations and Maintenance manual provided by CVI is kept in the MAGCOOL Control Room located in Building 902.
- 7.2 An Operators Problem Guide and Operations Guide is give to all operators and a copy is kept in the MAGCOOL Control Room located in Building 902.

## **8.0 Attachments**

None