

[illegible]

1        Scope:

This procedure describes the methods used to perform warm and cold integral testing of LHC D1/D2/D3/D4 magnet assemblies. Warm and Cold tests are performed separately or together as a part of magnet acceptance procedures. They are also performed as an "in-process" test to ensure the quality of a magnet assembly prior to completion.

2        Applicable Documents:

RHIC-MAG-Q-1004                      Discrepancy Reporting Procedure

3        Requirements:

3.1      Material/Equipment:

See procedure.

3.2      Safety Precautions:

3.2.1    Ensure magnetic field strengths have been measured or calculated and the required postings are in place as per the Static Magnetic Field SBMS Subject Area: <https://sbms.bnl.gov/standard/1u/1u00t011.htm>

### 3.3 Warm Integral Coil Measurement Runs

#### 3.3.1 Instruments and Devices Required:

- Integral Coil
- Integral Coil Insertion and Rotation Tool for moving the integral coil into the magnet
- PC with HTBasic and IEEE488 card
- Six HP Digital Multimeters (6 HP3458A's)
- D/Q Dual Mode (QCD) Warm Power Supply

#### 3.3.2 Cable Connections

	<b>Address</b>	<b>Meter</b>	<b>Input</b>	<b>Trig</b>
1	725	3458A	Coil 1	Ext <sup>¶</sup>
2	726	3458A	Coil 2	Ext
3	727	3458A	DCCT 1	Ext
4	728	3458A	DCCT 1	Ext
5	729	3458A	Coil 1	Ext
6	730	3458A	Coil 2	Ext

<sup>¶</sup>All external triggers come from the IOtech 488HR in the D/Q WPS rack.

#### **Note**


**There are only three signals and each signal is T'd so that each one goes to two meters.**

If the PC is one contained in a cart, it is important to avoid potential address conflicts between any devices in the cart and the other devices (the HP 3458A DMMs). Either disconnect the IEEE 488 cable connections between the computer and the devices in the cart that are not being used, or make certain that none of the DVM addresses conflict.

### 3.3.3 Setup

3.3.3.1 Turn on HP 3458A DVMs 4 hrs. before starting.

3.3.3.2 Place the integral coil in the middle of the magnet and at the nominal rotation angle as per standard test procedures. See figure below.



#### NOTE

**Middle of magnet cryostat (from end flange "D") is also the location of magnet cold mass middle.**

3.3.3.3 Connect the D/Q power supply cable to the connectors using the same hook-up as for warm measurements.

3.3.3.4 Turn on the D/Q Warm Power Supply

3.3.3.5 Log into the network.

3.3.3.6 At the DOS prompt, enter "HTB". Then get and run the file "INTCOIL.W5T".

3.3.3.7 Enter Test as the run number (the entry is not case sensitive).

3.3.3.8 If  $N_{pass} \neq 1$ , set  $N_{pass}$  to 1.

3.3.3.9 Observe the resistance readings for each of the two coils, the values should be 2380 ohms  $\pm$  50 ohms (each BNC - Fixed Integral Coil).

### NOTE

#### **This resistance will vary with temperature**

- 3.3.3.10 Toggle Plot to “yes” if necessary — “yes” is the default
- 3.3.3.11 Take a test read by pressing the *Ramp:I* key, the plot should look something like the one attached.
- 3.3.3.12 Observe the two boxed quantities (C1 & C2) in the upper right corner of the plot. The numbers should be about equal in magnitude ( $\sim 0.29$ ) but opposite in sign. If they are not, then it is necessary to rotate the coil form until they are.

### NOTE

#### **Two runs are to be performed:**

**In the first run, measurements are taken at a single rotation position where  $C1 \approx -0.29$  and  $C2 \approx +0.29$ .**

**In the second run, the coil form is rotated until one signal (C1) is  $0.000 \pm 0.005$  V. Readings are taken and then the coil form is rotated so that the signal is  $-0.030 \pm 0.005$  V. This process continues until the voltage on the observed coil is  $\sim -0.300 \pm 0.005$  V (that is, about the same as the voltage on the other coil (C2), which has been decreasing as the coil form was rotated). Then the *other* coil is monitored and the coil form is rotated to reduce its voltage to 0.000 V in 0.030 V steps.**

- 3.3.4 Performing the First Run
  - 3.3.4.1 Restart the program. Enter an actual Run Number using the standard style.
  - 3.3.4.2 To prepare for the set of measurements, press the *Adj. Coil* key. Observe the line printed out that gives the values for the average voltages on Coils 1 and 2. If  $C1 \neq -0.29 \pm 0.009$ , rotate the coil form, press the *Adj. Coil* key again to acquire a new reading, and observe the new values reported for the average voltages on the coils. Next, if the magnitudes of the voltages on C1 and C2 (ignore the sign of the voltage) are not equal to within  $\pm 0.005$  V, rotate the coil form until this condition is satisfied.
  - 3.3.4.3 Mark the Integral Coil Insertion and Rotation Tool for this angular position.
  - 3.3.4.4 If  $N_{pass} \neq 20$ , use the *Npass* key and set *Npass* to 20.
  - 3.3.4.5 Toggle Hard Copy to “yes”.

3.3.4.6 Take two (2) sets of 20 measurements. Each press of the *Ramp:1* key provides one set of measurements.

*Steps 3.3.4.7 and 3.3.4.8 are optional. Do the following two steps only if requested to do so.*

3.3.4.7 Move the coil longitudinally, inserting it two (2) additional inches into the magnet. Verify that C1 and C2 have the same magnitude to within  $\pm 0.005$ . Set  $N_{pass} = 10$ . Take two (2) sets of 10 measurements.

3.3.4.8 Move the coil out longitudinally four (4) inches, so that it is two (2) inches *farther out* of the magnet than it was when it was centered. Verify that C1 and C2 have the same magnitude to within  $\pm 0.005$ . Set  $N_{pass} = 10$ . Take two (2) sets of 10 measurements.

*End of Optional steps.*

3.3.4.9 Transfer the data using the Network key.

3.3.4.10 Exit the program.

3.3.4.11 Return the coil form to its centered position.

3.3.5 Performing the Second Run

3.3.5.1 Restart the program. Enter an actual Run Number using the standard style.

3.3.5.2 To prepare for the set of measurements, press the *Adj. Coil* key. Observe the line printed out that gives the values for the average voltages on Coils 1 and 2. If  $ABS(C1) \neq 0.000 \pm 0.005$ , rotate the coil form, press the *Adj. Coil* key again to acquire a new reading, and observe the new values reported for the average voltages on the coils. Repeat the process of rotating the coil form and pressing the *Adj. Coil* key until  $ABS(C1) = 0.000 \pm 0.005$ .

3.3.5.3 Mark the Integral Coil Insertion and Rotation Tool for this angular position.

3.3.5.4 If  $N_{pass} \neq 5$ , use the *Npass* key and set  $N_{pass}$  to 5.

3.3.5.5 Toggle Hard Copy to “yes”.

3.3.5.6 Take one (1) set of 5 measurements by pressing of the *Ramp:1* key once.

- 3.3.5.7 Rotate the coil form so that the signal [- (C1)] is  $0.030 \pm 0.005$  V by first turning the coil form a small amount, then pressing the *Adj. Coil* key to see what the voltages are and repeating this process until the voltage has the desired magnitude. Be sure to mark on the coil form which way you are rotating it relative to the position in the preceding step so that you can continue to move in this direction when you go on to the next position. As getting to within  $\pm 0.005$  V at each position is a trial and error procedure and thus may require rotating the coil form first one way and then the other, it is easy to get confused about the general direction you are going as you move from one measurement position to the next. Once you have obtained the proper position as indicated by the voltages reported by pressing the *Adj. Coil* key, you are ready to take the measurements at this position. To do so, press the *Ramp:1* key once. (*Npass* remains at the value 5 for all the measurement positions).
- 3.3.5.8 Rotate the coil form (continuing in the same direction) until the magnitude of the voltage on Coil 1 is  $0.060 \pm 0.005$  using the same procedure as in the step above. Once the position has been reached, press the *Ramp:1* key once.
- 3.3.5.9 Continue on in this way for positions where the magnitude of the voltage on Coil 1 is -0.090, -0.120, -0.150, -0.180, -0.210, -0.240, -0.270, and -0.300 V.
- 3.3.5.10 Now shift your attention to the voltages on Coil 2. The magnitudes of these voltages have been decreasing as the magnitudes of the voltages on Coil 1 increased. Rotate the coil form (still continuing in the same rotation direction) until the voltage on Coil 2 is  $0.270 \pm 0.005$  V. Once this position has been obtained (again using the *Adj. Coil* key to measure the voltages on the coils and thus find the position), press the *Ramp:1* key once to take the five measurements at this position.
- 3.3.5.11 Continue on in this way for positions where the magnitude of the voltage on Coil 2 is +0.240, +0.210, +0.180, +0.150, +0.120, +0.090., +0.060, +0.030, and 0.000 V.
- 3.3.5.12 Transfer the data using the Network key. Exit the program.

### 3.4 Cold Integral Coil Measurement Runs

#### 3.4.1 Instruments and Devices Required:

- Integral Coil
- Long Integral Coil Insertion and Rotation Tool for moving the integral coil into the magnet
- PC with HTBasic and IEEE488 card in Horizontal Control Room
- Three HP Digital Multimeters (3 HP3458A's)
- IOtech DAC 488/HR

#### 3.4.2 Cable Connections

##### DVMs

	<b>Address</b>	<b>Meter</b>	<b>Input</b>	<b>Trig</b>
1	727	3458A	MPS DCCT	Ext <sup>¶</sup>
2	728	3458A	Coil 1	Ext
3	729	3458A	Coil 2	Ext

<sup>¶</sup>All external triggers come from the IOtech 488HR, Port 1.  
NOTE: Do NOT use the IOtech 488HR Trigger Out BNC.

##### IOtech 488HR

Connect the trigger cable for the DVMs to Port 1.  
Connect the ) -MPS cable to Port 2.

##### MPS

At one point in the procedure, you will need to connect the other end of the ) -MPS cable to a card in the MPS control racks, and to flip a switch on that card from **I**nternal to **X**ternal.

The meters and IOtech 488HR should be connected through the fiber optic extension of the HP-IB bus that is normally used to connect to the transporter controller. It is probably advisable to disconnect the instruments in the vertical rack that is used for the mole runs in order to avoid address conflicts.



There will be more than three HP 3458A DVMs in the rack. Disconnect the HP-IB cable going from the third DVM to the ones below it so you don't have to worry about their address settings. Use the short HP-IB cable to connect the IOtech 488HR to one of the three DVMs below. Connect a HP-IB cable between the fiber optic HP-IP Extender and the instruments in the rack.

#### **NOTE**

**Do not try to eliminate an address conflict by turning off the unused meters. Rather, change their addresses or disconnect the HP-IB cable.**

**In addition to the HP-IB cable (IEEE488) that connects all the meters, there is also a trigger cable. All the meters are connected in parallel at their Ext. Trig BNCs to the trigger cable. If one or more of the meters below are turned off, the trigger signal will be loaded down and the meters in use may not be triggered. (Actually, this problem with triggers has only been observed when the trigger signal came from one of the Buckets for the rotating coils rather than from a DAC, but it's a good idea to leave the meters "on" in any case so they will be warmed up and ready for any subsequent measurements that may need them.)**

### 3.4.3 Setup

3.4.3.1 Turn on HP 3458A DVMs 4 hrs. before starting.

3.4.3.2 Place the integral coil in the middle of the magnet and at the nominal rotation angle as explained in this paragraph. The integral coil is 410.125" long. There is a mark on the integral coil insertion and rotation tool that indicates how far in to push the integral coil. Also, on the tip of the tool (at the operator's end, not the coil end), is a short line. This line should be placed at the top to properly orient the integral coil inside the magnet.

3.4.3.3 Connect all the equipment cables.

3.4.3.4 Turn on the MPS and bring it to 50 A.

3.4.3.5 Log into the network.

3.4.3.6 At the DOS prompt, enter "HTB". Then get and run the file "INTCOLD.C3".

3.4.3.7 Answer the question about whether the Time as reported by the computer clock is correct.

- 3.4.3.8 Enter the magnet name, then the Run Number using the standard style.
- 3.4.3.9 Tell the program that the ramp rate (also known as  $\dot{I}$ , Idot, or Irate) will be 20 A/s,  $I_{end}$  will be 5900 A, and  $I_{start}$  will be 50 A, when asked.
- 3.4.3.10 Adjust the coil position. Set up the meters for taking the readings for adjusting the coil position by pressing the *Adjust Coil* button and then answering “Y” (default) to the question about whether this is a manual adjustment. The “manual” choice will result in the program simply configuring the meters appropriately to see the voltages, but won't cause data to be stored or moved about.
- 3.4.3.11 Enter the command to ramp the MPS from 50 A to 5900 A and then back to 50 A at 60 A/s. Immediately after you press *Return* to start the ramping, go out to the magnet where the integral coil is located. Observe the voltage readings. They should be about equal ( $\pm 0.005$  volts), and have opposite sign. If they aren't, use the coil insertion and rotation tool to rotate the coil. If you don't succeed in getting the proper orientation during the first ramp, go back to the control room, start another up and down ramp, and try again.
- 3.4.3.12 As soon as you have the voltages about equal, go to the MPS racks. Observe the reading on the HP 3456A there and, if the MPS is still ramping, wait until the current is stable at 50 A. (Expect a reading of about 0.0499 V on the HP 3456A.) Then remove the cover for the ) I controller for the ramps, plug in the ) I cable, and flip the switch from **I** to **X** (for externally controlled). After you have flipped the switch, you can request the MPS to ramp, but no ) I current changes will occur unless pulses are received from the IOtech 488HR. However, you must not enter the commands too early either, since the IOtech488HR over-pulses in order to insure that the desired end current is reached. If the command for the down ramp is entered while the IOtech488HR is over pulsing at the flat top, the MPS will begin ramping down but won't receive enough pulses to complete the down ramp. Now that everything is done from the control room, coordinating the data acquisition and MPS control is simple. (See steps below.)

### NOTE

Six runs are to be performed.

Run	I at Start	I at End	Ramp Rate
1	50 A	5900 A	20 A/s
2	5900 A	50 A	20 A/s
3	50 A	5900 A	40 A/s
4	5900 A	50 A	40 A/s
5	50 A	5900 A	60 A/s
6	5900 A	50 A	60 A/s

Note that Run 2 is the down-ramp of Run 1, Run 4 is the down-ramp of Run 3, etc.

#### 3.4.4 Performing the Runs

### NOTE

The program is not run four times as you might expect. The program creates a file with the Run Number that is the same as that for the first run, then creates four (or as many as needed) data files which are later analyzed and used to create four ASCII files that have the expected names. The ASCII files are then transferred to the network. The file on the PC with the Run Number is not a critical file, since it has little information in it except at what number to begin naming the analyzed data files. Don't worry if you have to restart the program and somehow overwrite or purge this file. The program will automatically avoid overwriting any actual data files no matter how many times the program is restarted.

- 3.4.4.1 If Idot is not correct for the ramp to be measured, press the *Change Idot* button and set it correctly. You will also be asked whether the beginning current has been changed. Since we no longer do measurements at different beginning currents, you may always just press Enter.

- 3.4.4.2 Press the *Enable Ramp* button.
- 3.4.4.3 **Wait for the PC to display that it is Ready to generate the ramp.** (This means that it is ready to send the ) I pulses to generate enough ) I steps to take the current from its present value to the desired end value. It will also generate enough DVM triggers before starting the ramp and at the end to get flat regions both before and after.).
- 3.4.4.4 Enter the appropriate ramp command at the micro-VAX workstation. If the PC is displaying that it is ready to generate the ramp, then press the Return key on the micro-VAX keyboard. **Wait for the PS Status display to show “Holding.”**
- 3.4.4.5 Press the Continue key on the PC computer keyboard. After a slight delay to record a flat region, the current should start ramping. If nothing appears to happen, you may have pressed the Enter key by mistake. No harm was done if you did, so go ahead and press the Continue key. The PC display will show the expected time for the ramp and how much of that time has expired. When the two times are about equal, it will begin transferring the data points stored in the three HP DVM's across the HP-IB bus and into the computer's RAM memory. It will then plot the data on the screen.
- 3.4.4.6 Unless there is something clearly wrong with the data, press Enter in order to input the default response of “Y” to the question as to whether you wish to store the data. The data will then be stored on the hard disc. (The “active” light for the PC hard disc will flash.) If the data do not look right, you will need to figure out what is wrong or to get help.
- 3.4.4.7 After some analysis of the data, the computer will ask whether you want to print out the results for the ramp. The default answer is “N”, which is the desired answer, so just press Enter.
- 3.4.4.8 Repeat steps 3.4.4.3 through 3.4.4.6 for the “Down” ramp. (You don't have to press the *Enable Ramp* button this time, since the program assumes that what goes Up must come Down.).
- 3.4.4.9 Repeat steps 3.4.4.1 through 3.4.4.8 for the “Up” and “Down” ramps at 80 A/s.
- 3.4.4.10 Press the *Network* button. The program will count the number of data files created and then suggest the run numbers to reserve for these runs.

- 3.4.4.11 The program “d:\intcoil\Plt.BLI” will then be automatically loaded and started. You will be asked whether you want a hard copy of the plots and whether to create the data transfer files. Answer “Y” to the second question.
- 3.4.4.12 Respond to the program’s prompts, either confirming the Magnet name and first run number or entering new values.
- 3.4.4.13 Plt.BLI will now automatically read each of the data files created, plot the raw data ( $I_m$ ,  $V_{c1}$ , and  $V_{c2}$ ), and analyze it (including computing BLI and plotting it). An ASCII \*.dat file will be created for each run automatically. After each analysis, the \*.dat file and the raw data files will be copied from the PC to the network file server by the program. You may continue with the following steps while the program performs these operations.
- 3.4.4.14 Go out to the MPS and remove the ) -MPS cable from the card. Stick it under the handle where you got it so it will be easy to find next time. Then flip the switch from **X** to **I**, and replace the cover.
- 3.4.4.15 Ramp down the MPS and turn it off.
- 3.4.4.16 Remove the integral coil.
- 3.4.4.17 Return the HP-IB Fiber Optic Extender to the Transporter Controller and hook the cables back up both there and in the vertical rack used for the instruments for the mole measurements at the horizontal bays.
- 3.4.4.18 Return the DVMs to a storage location and leave them plugged in and turned on.

4            Quality Assurance Provisions

4.1           The Quality Assurance provisions of this procedure require that the technician shall be responsible for performing all operations in compliance with the procedural instructions contained herein and the recording of the results on the production traveler.

4.2           The technician is responsible for notifying the technical supervisor and/or the cognizant engineer of any discrepancies occurring during the performance of this procedure. All discrepancies shall be identified and reported in accordance with RHIC- MAG-Q-1004.

4.3           Measuring and test equipment used for this procedure shall contain a valid calibration label in accordance with RHIC-MAG-Q-1000, where applicable.

5            Preparation for Delivery:


N/A

**The only official copy of this file is the one on-line on the Superconducting Magnet Division website. Before using a printed copy, verify that it is the most current version by checking the document issue date on the website.**

LHC-MAG-R-1052B


Page 14 of 23

**Figures on following pages are reference plots of warm and cold results.**



13:34:14	Ramp:	59.0 +0.59584	30.44798	0.198739	66.574449
13:34:50	Ramp:	59.0 +0.59562	30.44803	0.198762	66.581584
13:34:58	Ramp:	59.0 +0.59590	30.44814	0.198745	66.576396
13:35:01	Ramp:	59.0 +0.59634	30.44851	0.198743	66.575637
13:35:05	Ramp:	59.0 +0.59590	30.44812	0.198750	66.577887
13:35:09	Ramp:	59.0 +0.59643	30.45000	0.198761	66.578668
13:35:13	Ramp:	59.0 +0.59605	30.44840	0.198752	66.578269
13:35:16	Ramp:	59.0 +0.59635	30.44791	0.198743	66.577001
13:35:20	Ramp:	59.0 +0.59592	30.44833	0.198751	66.578028
13:35:24	Ramp:	59.0 +0.59598	30.44813	0.198741	66.575009
13:35:28	Ramp:	59.0 +0.59584	30.44837	0.198743	66.574977
13:35:31	Ramp:	59.0 +0.59575	30.44789	0.198736	66.573388
13:35:35	Ramp:	59.0 +0.59564	30.44803	0.198737	66.573275
13:35:39	Ramp:	59.0 +0.59650	30.44807	0.198746	66.578109
13:35:42	Ramp:	59.0 +0.59621	30.44830	0.198754	66.579445
13:35:46	Ramp:	59.0 +0.59611	30.44887	0.198753	66.577762
13:35:50	Ramp:	59.0 +0.59591	30.44865	0.198752	66.577379
13:35:54	Ramp:	59.0 +0.59591	30.44849	0.198758	66.579965
13:35:57	Ramp:	59.0 +0.59613	30.44866	0.198744	66.575312
13:36:01	Ramp:	59.0 +0.59633	30.44821	0.198749	66.578474
1 13:36:01	Ramp:	59.0 +0.59603	30.44836	0.198748	66.577051 (4533)2152
C1 -0.2923554 C2 +0.2926535 $\sqrt{(C1^2+C2^2)}$ 0.4136638 $ C1 - C2 $ -0.0003					
13:36:12	Ramp:	59.0 +0.59547	30.44751	0.198749	66.578012
13:36:16	Ramp:	59.0 +0.59616	30.44789	0.198744	66.577081
13:36:19	Ramp:	59.0 +0.59592	30.44765	0.198745	66.577321
13:36:23	Ramp:	59.0 +0.59571	30.44839	0.198744	66.574874
13:36:27	Ramp:	59.0 +0.59603	30.44823	0.198738	66.573862
13:36:30	Ramp:	59.0 +0.59626	30.44795	0.198739	66.575346
13:36:34	Ramp:	59.0 +0.59600	30.44736	0.198738	66.575735
13:36:38	Ramp:	59.0 +0.59641	30.44830	0.198750	66.578796
13:36:42	Ramp:	59.0 +0.59628	30.44740	0.198741	66.577236
13:36:45	Ramp:	59.0 +0.59592	30.44786	0.198750	66.578598
13:36:49	Ramp:	59.0 +0.59560	30.44826	0.198748	66.576215
13:36:53	Ramp:	59.0 +0.59562	30.44793	0.198755	66.579319
13:36:57	Ramp:	59.0 +0.59612	30.44823	0.198756	66.580130
13:37:00	Ramp:	59.0 +0.59617	30.45092	0.198774	66.580244
13:37:04	Ramp:	59.0 +0.59618	30.44814	0.198743	66.576051
13:37:08	Ramp:	59.0 +0.59586	30.44798	0.198744	66.576225
13:37:11	Ramp:	59.0 +0.59588	30.44832	0.198745	66.575645
13:37:15	Ramp:	59.0 +0.59651	30.44957	0.198751	66.576396
13:37:19	Ramp:	59.0 +0.59576	30.44816	0.198741	66.574432
13:37:23	Ramp:	59.0 +0.59608	30.44768	0.198735	66.574378
2 13:37:23	Ramp:	59.0 +0.59600	30.44819	0.198746	66.576795 (3449)1848
C1 -0.2923457 C2 +0.2926583 $\sqrt{(C1^2+C2^2)}$ 0.4136604 $ C1 - C2 $ -0.0003					
13:48:28	Ramp:	59.0 +0.59449	30.44885	0.198766	66.578676






	13:48:44	Ramp: 59.0 +0.59416	30.44994	0.198781	66.580539	
	13:49:20	Ramp: 59.0 +0.59374	30.45041	0.198783	66.578950	
	13:49:24	Ramp: 59.0 +0.59499	30.44938	0.198759	66.575984	
	13:49:28	Ramp: 59.0 +0.59513	30.45013	0.198764	66.576473	
	13:49:32	Ramp: 59.0 +0.59496	30.44992	0.198763	66.576305	
1	13:49:32	Ramp: 59.0 +0.59460	30.44996	0.198770	66.577650	(2888)1789
		C1 +0.0002296 C2 +0.4137096 $\sqrt{(C1^2+C2^2)}$ 0.4137096		C1 - C2	-0.4135	
	13:51:00	Ramp: 59.0 +0.59438	30.44837	0.198773	66.581670	
	13:51:04	Ramp: 59.0 +0.59498	30.44816	0.198766	66.581148	
	13:51:08	Ramp: 59.0 +0.59483	30.44914	0.198773	66.580969	
	13:51:11	Ramp: 59.0 +0.59479	30.44871	0.198763	66.578430	
	13:51:15	Ramp: 59.0 +0.59435	30.44874	0.198773	66.580844	
2	13:51:15	Ramp: 59.0 +0.59467	30.44862	0.198769	66.580612	(2182)1127
		C1 -0.0295966 C2 +0.4126485 $\sqrt{(C1^2+C2^2)}$ 0.4137086		C1 - C2	-0.3831	
	13:54:37	Ramp: 59.0 +0.59385	30.44780	0.198766	66.579390	
	13:54:41	Ramp: 59.0 +0.59479	30.44907	0.198783	66.584410	
	13:54:44	Ramp: 59.0 +0.59525	30.44876	0.198768	66.581223	
	13:54:48	Ramp: 59.0 +0.59442	30.44951	0.198778	66.580924	
	13:54:52	Ramp: 59.0 +0.59498	30.44900	0.198777	66.582888	
3	13:54:52	Ramp: 59.0 +0.59466	30.44883	0.198774	66.581767	(2643)1726
		C1 -0.0619801 C2 +0.4090496 $\sqrt{(C1^2+C2^2)}$ 0.4137187		C1 - C2	-0.3471	
	13:55:48	Ramp: 59.0 +0.59427	30.44855	0.198777	66.582475	
	13:55:51	Ramp: 59.0 +0.59501	30.44933	0.198777	66.582205	
	13:55:55	Ramp: 59.0 +0.59501	30.44933	0.198765	66.578294	
	13:55:59	Ramp: 59.0 +0.59494	30.44878	0.198772	66.581578	
	13:56:03	Ramp: 59.0 +0.59439	30.44939	0.198785	66.583600	
4	13:56:03	Ramp: 59.0 +0.59473	30.44908	0.198775	66.581630	(3336)1792
		C1 -0.0906561 C2 +0.4036657 $\sqrt{(C1^2+C2^2)}$ 0.4137203		C1 - C2	-0.3130	
	13:57:32	Ramp: 59.0 +0.59413	30.44883	0.198781	66.582839	
	13:57:36	Ramp: 59.0 +0.59449	30.44894	0.198778	66.582284	
	13:57:40	Ramp: 59.0 +0.59477	30.44840	0.198771	66.581974	
	13:57:44	Ramp: 59.0 +0.59467	30.44880	0.198775	66.582204	
	13:57:47	Ramp: 59.0 +0.59492	30.44853	0.198774	66.583049	
5	13:57:47	Ramp: 59.0 +0.59459	30.44870	0.198776	66.582470	( 579) 406
		C1 -0.1199822 C2 +0.3959423 $\sqrt{(C1^2+C2^2)}$ 0.4137221		C1 - C2	-0.2760	
	13:59:56	Ramp: 59.0 +0.59461	30.44840	0.198781	66.584812	
	13:59:59	Ramp: 59.0 +0.59456	30.44862	0.198775	66.582374	
	14:00:03	Ramp: 59.0 +0.59393	30.44835	0.198773	66.580590	
	14:00:07	Ramp: 59.0 +0.59441	30.44838	0.198782	66.584777	
	14:00:10	Ramp: 59.0 +0.59448	30.44910	0.198774	66.580556	
6	14:00:10	Ramp: 59.0 +0.59440	30.44857	0.198777	66.582622	(2190)1892
		C1 -0.1491731 C2 +0.3858950 $\sqrt{(C1^2+C2^2)}$ 0.4137241		C1 - C2	-0.2367	

	14:01:50	Ramp: 59.0 +0.59369	30.44858	0.198787	66.584429	
	14:01:54	Ramp: 59.0 +0.59394	30.44761	0.198775	66.583271	
	14:01:58	Ramp: 59.0 +0.59429	30.45117	0.198804	66.585790	
	14:02:01	Ramp: 59.0 +0.59433	30.44845	0.198768	66.579679	
	14:02:05	Ramp: 59.0 +0.59410	30.44836	0.198767	66.579084	
7	14:02:05	Ramp: 59.0 +0.59407	30.44883	0.198780	66.582451	(3367)2637
C1	-0.1793387	C2 +0.3728419	$\sqrt{(C1^2+C2^2)}$	0.4137312	C1 - C2	-0.1935
	14:04:17	Ramp: 59.0 +0.59341	30.44774	0.198771	66.580358	
	14:04:20	Ramp: 59.0 +0.59393	30.44851	0.198777	66.581621	
	14:04:24	Ramp: 59.0 +0.59438	30.44843	0.198769	66.580238	
	14:04:28	Ramp: 59.0 +0.59371	30.44889	0.198776	66.580165	
	14:04:32	Ramp: 59.0 +0.59394	30.44797	0.198770	66.580571	
8	14:04:32	Ramp: 59.0 +0.59388	30.44831	0.198773	66.580590	(1030) 533
C1	-0.2104770	C2 +0.3561735	$\sqrt{(C1^2+C2^2)}$	0.4137151	C1 - C2	-0.1457
	14:06:16	Ramp: 59.0 +0.59335	30.44768	0.198779	66.582967	
	14:06:20	Ramp: 59.0 +0.59398	30.44893	0.198784	66.583428	
	14:06:23	Ramp: 59.0 +0.59449	30.44812	0.198768	66.580850	
	14:06:27	Ramp: 59.0 +0.59379	30.44819	0.198764	66.577654	
	14:06:31	Ramp: 59.0 +0.59414	30.44853	0.198761	66.576848	
9	14:06:31	Ramp: 59.0 +0.59395	30.44829	0.198771	66.580350	(3501)2687
C1	-0.2405610	C2 +0.3365831	$\sqrt{(C1^2+C2^2)}$	0.4137122	C1 - C2	-0.0960
	14:07:23	Ramp: 59.0 +0.59269	30.44848	0.198763	66.574247	
	14:07:26	Ramp: 59.0 +0.59369	30.44781	0.198766	66.579072	
	14:07:30	Ramp: 59.0 +0.59375	30.44813	0.198759	66.576029	
	14:07:34	Ramp: 59.0 +0.59363	30.44786	0.198770	66.580051	
	14:07:37	Ramp: 59.0 +0.59372	30.44821	0.198776	66.581685	
10	14:07:37	Ramp: 59.0 +0.59350	30.44810	0.198767	66.578217	(3969)2708
C1	-0.2698075	C2 +0.3136140	$\sqrt{(C1^2+C2^2)}$	0.4137026	C1 - C2	-0.0438
	14:09:30	Ramp: 59.0 +0.59327	30.44869	0.198756	66.572672	
	14:09:34	Ramp: 59.0 +0.59366	30.44804	0.198765	66.578224	
	14:09:37	Ramp: 59.0 +0.59344	30.44790	0.198766	66.578195	
	14:09:41	Ramp: 59.0 +0.59397	30.44825	0.198766	66.578651	
	14:09:45	Ramp: 59.0 +0.59359	30.44781	0.198760	66.576710	
11	14:09:45	Ramp: 59.0 +0.59358	30.44814	0.198762	66.576891	(4218)2209
C1	-0.2989882	C2 +0.2859170	$\sqrt{(C1^2+C2^2)}$	0.4136937	C1 - C2	+0.0131
	14:10:19	Ramp: 59.0 +0.59277	30.44815	0.198754	66.572104	
	14:10:23	Ramp: 59.0 +0.59361	30.44848	0.198758	66.574880	
	14:10:27	Ramp: 59.0 +0.59409	30.44879	0.198761	66.575968	
	14:10:30	Ramp: 59.0 +0.59386	30.44810	0.198753	66.574452	
	14:10:34	Ramp: 59.0 +0.59372	30.44834	0.198749	66.572228	
12	14:10:34	Ramp: 59.0 +0.59361	30.44837	0.198755	66.573926	(2042)1520
C1	-0.3130849	C2 +0.2703840	$\sqrt{(C1^2+C2^2)}$	0.4136782	C1 - C2	+0.0427
	14:12:11	Ramp: 59.0 +0.59210	30.44768	0.198726	66.562275	
	14:12:14	Ramp: 59.0 +0.59297	30.44788	0.198722	66.562715	
	14:12:18	Ramp: 59.0 +0.59351	30.44859	0.198729	66.564692	
	14:12:22	Ramp: 59.0 +0.59370	30.44860	0.198721	66.562282	
	14:12:25	Ramp: 59.0 +0.59323	30.44832	0.198717	66.560455	
13	14:12:25	Ramp: 59.0 +0.59310	30.44821	0.198723	66.562484	(2208)1351
C1	-0.3378614	C2 +0.2385885	$\sqrt{(C1^2+C2^2)}$	0.4136119	C1 - C2	+0.0993
	14:13:18	Ramp: 59.0 +0.59224	30.44713	0.198717	66.561095	
	14:13:22	Ramp: 59.0 +0.59347	30.44815	0.198717	66.561374	
	14:13:26	Ramp: 59.0 +0.59336	30.44939	0.198721	66.559895	
	14:13:29	Ramp: 59.0 +0.59337	30.44778	0.198715	66.561476	
	14:13:33	Ramp: 59.0 +0.59326	30.44822	0.198720	66.561717	
14	14:13:33	Ramp: 59.0 +0.59314	30.44813	0.198718	66.561111	(1217) 640
C1	-0.3554677	C2 +0.2114454	$\sqrt{(C1^2+C2^2)}$	0.4136018	C1 - C2	+0.1440

	14:15:03	Ramp:	59.0 +0.59251	30.44703	0.198685	66.550973	
	14:15:07	Ramp:	59.0 +0.59291	30.44805	0.198699	66.554319	
	14:15:11	Ramp:	59.0 +0.59277	30.44756	0.198696	66.554195	
	14:15:14	Ramp:	59.0 +0.59291	30.44812	0.198697	66.553637	
	14:15:18	Ramp:	59.0 +0.59313	30.44803	0.198700	66.555218	
15	14:15:18	Ramp:	59.0 +0.59285	30.44776	0.198695	66.553669	(2696)1440
	C1	-0.3727745	C2 +0.1790708	$\sqrt{(C1^2+C2^2)}$	0.4135543	C1 - C2	+0.1937
	14:16:47	Ramp:	59.0 +0.59184	30.44758	0.198689	66.549808	
	14:16:50	Ramp:	59.0 +0.59295	30.44775	0.198687	66.551056	
	14:16:54	Ramp:	59.0 +0.59229	30.44734	0.198680	66.548166	
	14:16:58	Ramp:	59.0 +0.59285	30.44807	0.198686	66.549794	
	14:17:02	Ramp:	59.0 +0.59283	30.44842	0.198696	66.552227	
16	14:17:02	Ramp:	59.0 +0.59255	30.44783	0.198688	66.550210	(2043)1364
	C1	-0.3849421	C2 +0.1511067	$\sqrt{(C1^2+C2^2)}$	0.4135380	C1 - C2	+0.2338
	14:18:37	Ramp:	59.0 +0.59225	30.44802	0.198682	66.547183	
	14:18:41	Ramp:	59.0 +0.59251	30.44773	0.198661	66.541394	
	14:18:45	Ramp:	59.0 +0.59293	30.44783	0.198661	66.542160	
	14:18:48	Ramp:	59.0 +0.59195	30.44734	0.198661	66.541247	
	14:18:52	Ramp:	59.0 +0.59225	30.44749	0.198664	66.542581	
17	14:18:52	Ramp:	59.0 +0.59238	30.44768	0.198666	66.542913	(4270)2191
	C1	-0.3953996	C2 +0.1209777	$\sqrt{(C1^2+C2^2)}$	0.4134930	C1 - C2	+0.2744
	14:21:00	Ramp:	59.0 +0.59180	30.44677	0.198660	66.541717	
	14:21:04	Ramp:	59.0 +0.59213	30.44728	0.198652	66.538744	
	14:21:08	Ramp:	59.0 +0.59223	30.44716	0.198654	66.539837	
	14:21:12	Ramp:	59.0 +0.59253	30.44669	0.198640	66.536895	
	14:21:15	Ramp:	59.0 +0.59226	30.44679	0.198645	66.537676	
18	14:21:15	Ramp:	59.0 +0.59219	30.44694	0.198650	66.538974	(2743)1693
	C1	-0.4031663	C2 +0.0916885	$\sqrt{(C1^2+C2^2)}$	0.4134608	C1 - C2	+0.3115
	14:22:10	Ramp:	59.0 +0.59163	30.44735	0.198638	66.532758	
	14:22:14	Ramp:	59.0 +0.59201	30.44743	0.198636	66.532647	
	14:22:18	Ramp:	59.0 +0.59204	30.44784	0.198640	66.533252	
	14:22:21	Ramp:	59.0 +0.59234	30.44772	0.198640	66.534048	
	14:22:25	Ramp:	59.0 +0.59222	30.44744	0.198634	66.532455	
19	14:22:25	Ramp:	59.0 +0.59205	30.44755	0.198638	66.533032	(1016) 572
	C1	-0.4089898	C2 +0.0604592	$\sqrt{(C1^2+C2^2)}$	0.4134343	C1 - C2	+0.3485
	14:23:48	Ramp:	59.0 +0.59176	30.44680	0.198640	66.534683	
	14:23:52	Ramp:	59.0 +0.59180	30.44771	0.198632	66.530238	
	14:23:56	Ramp:	59.0 +0.59220	30.44707	0.198634	66.533282	
	14:24:00	Ramp:	59.0 +0.59225	30.44697	0.198639	66.535184	
	14:24:03	Ramp:	59.0 +0.59215	30.44645	0.198638	66.535914	
20	14:24:03	Ramp:	59.0 +0.59203	30.44700	0.198637	66.533860	(3622)2004
	C1	-0.4122846	C2 +0.0307803	$\sqrt{(C1^2+C2^2)}$	0.4134320	C1 - C2	+0.3815
	14:26:24	Ramp:	59.0 +0.59144	30.44739	0.198621	66.526431	
	14:26:28	Ramp:	59.0 +0.59198	30.44715	0.198627	66.530273	
	14:26:32	Ramp:	59.0 +0.59171	30.44612	0.198625	66.531231	
	14:26:36	Ramp:	59.0 +0.59165	30.44689	0.198627	66.529862	
	14:26:39	Ramp:	59.0 +0.59176	30.44642	0.198615	66.527235	
21	14:26:39	Ramp:	59.0 +0.59171	30.44679	0.198623	66.529006	(2575)1847
	C1	-0.4134024	C2 -0.0009673	$\sqrt{(C1^2+C2^2)}$	0.4134035	C1 - C2	+0.4124

Press CONT (Alt+F2) if OK. BL/I vs. Angle



D1L101.023 18 Mar 2002 13:46:17

1	+0.0002296	+0.4137096	-45.0	66.577650
2	-0.0295966	+0.4126485	-40.9	66.580612
3	-0.0619801	+0.4090496	-36.4	66.581767
4	-0.0906561	+0.4036657	-32.3	66.581630
5	-0.1199822	+0.3959423	-28.1	66.582470
6	-0.1491731	+0.3858950	-23.9	66.582622
7	-0.1793387	+0.3728419	-19.3	66.582451
8	-0.2104778	+0.3561735	-14.4	66.580590
9	-0.2405618	+0.3365031	-9.4	66.580350
10	-0.2698075	+0.3136140	-4.3	66.578217
11	-0.2989882	+0.2859170	1.3	66.576891
12	-0.3130849	+0.2703840	4.2	66.573926
13	-0.3378614	+0.2385885	9.8	66.562484
14	-0.3554677	+0.2114454	14.3	66.561111
15	-0.3727745	+0.1790708	19.3	66.553669
16	-0.3849421	+0.1511067	23.6	66.550210
17	-0.3953996	+0.1209777	28.0	66.542913
18	-0.4031663	+0.0916085	32.2	66.538974
19	-0.4089898	+0.0604592	36.6	66.533032
20	-0.4122846	+0.0307883	40.7	66.533860
21	-0.4134024	-0.0009673	45.1	66.529886

18 Mar 2002 14:28:01

1 Ramp: 1 2 Network 3 Adj: Control 4 Npass: 5 5 ICR: gen  
6 Plot: Exit 7 8 DPS: Control 9 DUMP: no 6 PLT: no

